



- \*3 3A For 120, 1.6A For 230/240V
- \*6 Isolate J1 ,J2 and J3 From The Chassis
- \*7 Ground J4, J5 and J7 To The Chassis
- \*8 Choose the correct primary wire for your country's mains voltage

<b>ROSAMP amplification</b>	
TITLE: SLO 30 Schematic	
Document Number:	REV: 1.1
Date: 16/02/2024 14:08	Sheet: 1/1